



Part No. ALL34145

Crankcase Evacuation System

Reduce crankcase pressure for optimum piston ring seal, fewer oil leaks and better engine performance. System includes two each: chrome plated push-in valve cover breathers, check valves, weld-in 3.5" long threaded pipe adapters, rubber breather grommets, and four hose clamps. System does not include evacuation hoses.



Part No. Replacement Part
ALL34146.....Check Valve



REV071816

Check out the collection of replacement emission control parts we offer.