

Dry Break Redhead Valve

Safe and effective method for refueling prevents fluid loss. Spring loaded female receptacle mounts in a variety of locations and automatically closes when male dry break is removed. Female dry break accepts 2-1/2" fuel hose. Male dry break accepts 2-1/4" fuel hose.

Part No.	Description
ALL40213	Female Dry Break
ALL40215	Male Dry Break



Replacement Components:

ALL99028......Seal Kit For ALL40213 ALL99029.....Seal Kit For ALL40215