

Solenoid Jumper Wires

Jumper wire completes the circuit to the starter solenoid on the starter when using remote mounted solenoids such as ALL76203.

Part No. Description

ALL76208......Jumper Wire With Spade Terminal ALL76209......Jumper Wire With Ring Terminal

