



**Read complete instructions
before installation!
Improper installation may
void warranty**



Tools needed
Wire Strippers
Pliers



Remove the 2 pins located
at the top of the light



Pull the headlight assembly out



Unclip the 2 connectors on the
back of the light



Remove the parking light



Tap the 2 red wires into the parking
parking lights using the supplied
wire taps. One for power one for
ground. These wires are for your
Halo's.

Reassemble the light back into the vehicle by reversing these steps.
Be sure not to pinch the wires in between anything.
When you are finished installing your new Anzo Headlight check
for proper functions, example: headlight, turn signal, halos.

