

## Read complete instructions before installation! Improper installation may void warranty



Tools Needed: Phillips Screw Driver



Step 1: Lower the tail gate exposing the two screws.



Step 2; Remove the upper and lower screws



Step 3: Remove the taillight by pulling straight out.



Step 4: Remove all 3 sockets from the taillight housing.



Step 5: Remove the bulbs from the two black sockets.





Step 6: Place the resistor in a safe location in the housing.



Step 7: Connect the pigtails to the stock sockets.



Make sure the wires match: Black to Black



Step 8: Connect the resistor to the taillight housing.



Step 9: Place the LED taillight into the truck housing, secure with screws.



Make sure all functions are working properly be fore driving.

Anzo Lights Custom Tail Lights