



Read complete instructions before installation! Improper installation may void warranty



Tools needed: Phillips screwdriver





Step 3: Use the phillips screwdriver to remove the two screws holding in the tail light.



Step 6: Peel off the protective cover from the resistors and place in the two holes onto the frame of the body.





Step 2: unclip the wire from the plastic clips.



Step 4: Remove the tail light.



Step 7: Plug the resistors in and the wire harness into the circuit board under the bed.



Step 1: Under the vehicle bed unplug the wire harness for the tail light.





Step 5: Pull the wire out from under the bed.



Step 8: Test all functions making sure all functions work before driving.