



Completely read all the instructions before installation
Improper installation will void warranty!

Step 1

Tools needed:
Phillip Screw Driver

Step 2

Remove the two phillip screws

Step 3

Remove the third brake light by
disconnecting the brake light bulb
and the two reverse light bulb
sockets out of the third brake
light housing

Step 4

Remove the Anzo third brake
light out of its box

Step 5

Remove the brake light bulb out
of its socket

Step 6

Insert the Anzo brake light power
source directly into the brake light
harness socket

Step 7

Insert the reverse light bulb sockets
into the Anzo third brake light
housing

Step 8

Install the Anzo third brake light
by reversing step 2

Step 9

Be sure to test all functions before
operating the vehicle