

PATENT PRODUCT Grille Installation Instruction

Part#		0HFD6(;/S/J		Application		For 2006)6-2008 Toyota RAV4				
Parts L	Item	Part N	lame	QTY	Des	scription	Item	Part Name	QTY	Description	
	1	Billet Gri	lle	1	Stainl	less steel	2	Plastic Fasteners	4		
Install N	otes: Overlay \checkmark Replacement \times					nt 🛛	Drill	× Cut ×			
Step	Description						illustration				
1	Identify the grille & hardware with parts list.							I			
	Open the hood; remove the plastic fasteners retaining the radiator cover. Unscrew the hood stop bumpers on each end of the grille. Remove three plastic fasteners on top of the grille. Use a 10mm socket to remover the four bolts retaining the bottom of the grille. The factory grille has molded clips that clip into the bumper cover opening. Pull the bumper cover forward, away from the grille. It is necessary to use some force to separate the grille from the bumper cover (1&2). The bumper cover is a pliable plastic (it will not be damaged).										
2	forward, a	way from	the grill	le. It is ne	ecessa	ry to use so	me force				
1	forward, a bumper co	way from over is a pl	the grill iable pla	Ie. It is neastic (it wi	ecessa ill not b	of the bumpe	er cover. (to separate the grille from	the bumpe	r cover (1&2). The	
2	forward, a bumper co	way from over is a pl	the grill iable pla	Ie. It is neastic (it with a stic (it with a s	ecessa ill not b	of the bumpen	er cover. (e to separate the grille from	the bumpe	r cover (1&2). The	
1	forward, a bumper co	way from over is a pl	the grill iable pla	in the oper then proc	ecessa ill not b ening ching; th seed to The tal	of the bumpen step 4.	er cover. (the factor	to separate the grille from	the bumpe	r cover (1&2). The	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!