

PARTS BREAKDOWN



Parts List

| Index No. | Part No. | Description | Qty |
|------------------|-----------------|---|------------|
| 1 | 7801-01 | Oil Pressure Sending Unit Socket 1/2" Dr. x 29mm x 90mm | 1 |
| 2 | 7801-02 | Oxygen Sensor Socket 3/8" Dr. x 7/8" (22mm) x 90mm | 1 |
| 3 | 7801-03 | Injector Socket 1/2" Dr. x 1-1/16" (27mm) x 85mm | 1 |
| 4 | 7801-04 | Vacuum Switch Socket 3/8" Dr. x 7/8" (22mm) x 80mm | 1 |
| 5 | 7801-05 | Oil Pressure Sending Unit Socket 3/8" Dr. 1" & 1-1/16" (27mm) x 74mm | 1 |
| 6 | 7801-06 | Heated Oxygen Sensor Socket 1/2" Dr. x 7/8" (22mm) x 50mm | 1 |
| 7 | 7801-07 | Low Profile Offset Oxygen Sensor Socket 3/8" Dr. x 7/8" (22mm) x 30mm | 1 |