




ATD-5147



ITEM#	ORDERING PART#	PART DESCRIPTION
1	PRT5147-01	5/16" (3/4" DIAMETER) BRAKE SPRING TOOL
2	PRT5147-02	9-3/4" BRAKE SPRING TOOL
3	PRT5147-03	8-1/2" BRAKE BLEEDER WRENCH (5/16" AND 3/8" HEX BOX)
4	PRT5147-04	9" BRAKE BLEEDER WRENCH (1/4" AND 3/8" HEX BOX)
5	PRT5147-05	90° 5-1/8" BRAKE BLEEDER WRENCH (8MM AND 10MM)
6	PRT5147-06	8-3/16" BRAKE ADJUSTMENT TOOL (29° AND 45°)
7	PRT5147-07	8-1/4" BRAKE ADJUSTMENT TOOL (29° AND 45°)

Learn more about brake service tools we have.