

# INSTALLATION INSTRUCTIONS

## 2-1/16" Replacement Pillar F-150 15+ / Super Duty 17+ w/Speaker



Read through directions completely before starting installation.

- 1) Open factory handle covers and remove bolts w/10mm socket



- 2) Detach factory pillar by pulling towards yourself, then slide upwards towards headliner to release tabs from dash.

- 3) Unclip wire harness from speaker.

- 4) Remove factory speaker and grill. Install into pillar using supplied 4-40 screws



- 5) Install supplied snap nut into lower portion of slot



- 6) Connect speaker wire, insert bottom of pillar into dash area first.

**NOTE:** Caution must be taken NOT to over-tighten screw!

- 7) Insert screw into pillar, slide spacer over screw, align screw with snap nut and attach

