INSTALLATION INSTRUCTIONS



BLACK HORSE ROLL BAR FOR 1/2 TON TRUCKS (SIERRA 07-16, SILVERADO 07-16, F150 09-16, RAM 1500 09-16) FLAT BASE WITH LED BRAKE LIGHT

Before Installation

- Please read the instruction completely for easy installation, which will also help you to avoid scratches or other potential damages to your appealing car.
- The information shown here is for reference only and may differ from the product that you
 receive, however the goods are fitted in the same way.

Care and Cleaning

- Mild soap may be used also to clean the Product.
- Please periodically check and retighten all the hardware and clean the investment for a refresh look.

Parts list

NO.	QTY	PICTURE	NO.	QTY	PICTURE
1	1	Pipe 1	2	1	Pipe 2
3	1	Decoration plate-L	4	1	Decoration plate-R
(5)	2	Connecting plate (FOR LED LIGHT INSTALLATION)	6	2	Support plate


		INSTALLATION	INSTR	UCTIO	ONS
7	1	Allen wrench S=8	8	4	Gum cover
9	1	Allen wrench S=4	10	20	Flat washer D6
11)	10	Spring washer D6	12	4	Button head allen bolts M12-40
13	10	Hex nut M6	14	2	Button head allen bolts M6-30
15	8	Button head allen bolts M6-20	16	6	Spring washer D12
17	12	Flat Washer D12	18)	6	Hex nut M12
19	6	Hex nut M12*40			TION HOLIMIZ

INSTALLATION INSTRUCTIONS


Installation Fig.

Step 1: Verify all parts are present.

Step 2: Using wrench 9, install 1/2 main pipes and connecting plate 5 together with parts 10/11/13/14 as shown.




Step3: Using wrench 9, install 3/4 decoration plate together with parts 10/11/13/15 as shown.




Step4: Using wrench 7, install support plate 6 and gum cover 8 with part 12.

INSTALLATION INSTRUCTIONS



Step 4: Fix the roll bar on the trunk with parts 16/17/18/19 (need to drill the trunk if there's no installation holes). Test and make sure that the roll bar is steadily fixed, and then tighten all the hardware.



Step 6: Installation is finished, pick up all tools.

INSTALLATION INSTRUCTIONS TO THE PROPERTY OF THE PROPERTY OF

NOTE

Any damages and losses caused by improper installation and application, goes beyond our quality warranty.