



Crown Automotive Sales Co., Inc.

CJ Oil Pressure Gauge **Installation Instructions** Replaces Part #: J5750279

1. Before any electronics are removed, disconnect the battery.
2. Label wires prior to removal to aid in proper re-installation
3. Remove original oil pressure gauge, clean mounting surface, and install new oil pressure gauge. Slide mounting bracket onto the back of the gauge and install using the supplied hardware. Do not over-torque hardware as it may damage the gauge

Proper wiring is as follows:

- **S** Terminal – Oil Pressure Sender Wire (Purple)
- **G** Terminal – Ground (Black)
- **I** Terminal – Ignition-on Hot (Red)
- Spade Terminals – Illumination Power (Orange) & Ground (requires a separate ground)



4. Re-connect battery after gauge is installed and all wiring is connected to the gauge. Ensure all components are functioning properly.

Improperly wiring these gauges will result in gauge failure and will void the warranty.

While every attempt is made to ensure that the information contained in these instructions is correct, no liability can be accepted by the authors for loss, damage, or injury caused by any errors in, or omissions from the information given. All service should be performed by qualified mechanics. Crown Automotive Sales Co., Inc. cannot be held responsible for any mechanical work performed. Standard and accepted safety precautions should be used in every procedure.