



Instructions:

1. First drain out the transmission oil and then remove the oil sump.
2. Assemble the transmission oil drain tool kit (7650)
 - a. Connect the air with an air hose, and then connect the air hose with the air release valve
 - b. Select the correct adapter to the transmission.
 - i. BMW 6HP Adapter
 - ii. BMW 8HP Adapter
 - iii. Mercedes Benz 722.6 / 722.9 Adapter
 - c. Now connect the air pressure release valve to the adapter.
3. Fit the assembled adapter to the oil drain plug hole, open the air release valve, and increase the air pressure to 7-8 PSI. The remaining oil in the system will flush out.