



Cabin Air Filter

Removal & Installation Instructions

To maintain air conditioning efficiency, replace the air filter according to the manufacturer's maintenance schedule.

Always use an air filter. Removing the filter may decrease system performance by allowing dust to lower the efficiency of A/C and heating system components.

Prior to the installation of this DENSO First Time Fit® Cabin Air Filter, you must read these instructions completely.

Definition of Terms

△WARNING: Describes precautions that should be observed in order to prevent injury or death to the user during installation.

△CAUTION: Describes precautions that should be observed in order to prevent damage to the vehicle or its components, which may occur during installation if sufficient care is not taken.

NOTE: Provides additional information that facilitates installation work.

General Service Information and Requirements

△WARNING: To prevent the Supplemental Restraint System (SRS, Air Bag System) from operating, remove the ground (negative) cable from the battery, then wait at least 90 seconds before starting this procedure. This allows the backup power system to discharge.

NOTE: For more detailed instructions please refer to the vehicle manufacturer's service manual.

REQUIRED TOOLS:

- Safety Goggles
- Assorted Hand Tools

SAFETY PRECAUTIONS:

- Always wear safety goggles

Cabin Air Filter Removal

The information below explains necessary procedures and tools to remove and install the Cabin Air Filter (CAF).

1. Remove the passenger kick panel, located beneath the glove box.

NOTE: Four screws secure the panel.




Fig. 1

NOTE: The CAF access door is now visible.

2. Remove the access door screw and unhinge.
3. Remove the first filter by pulling it in a downward motion.
4. Slide the second filter forward, then in a downward motion to remove.
5. Discard the original filters.




Fig. 2

Cabin Air Filter Installation

6. Install the second filter by inserting it in an upward motion, then sliding it backwards.
7. Install the first filter by inserting it in an upward motion.
8. Reinstall CAF access door.
9. Reinstall the kick panel.




Fig. 3

Noise Test

10. Reconnect the battery ground cable.
11. Engine ON, A/C ON, blower speed on high.
12. Listen for any abnormal air noises from the air filter area.