



Cabin Air Filter

Removal & Installation Instructions

To maintain air conditioning efficiency, replace the air filter according to the manufacturer's maintenance schedule.

Always use an air filter. Removing the filter may decrease system performance by allowing dust to lower the efficiency of A/C and heating system components.

Prior to the installation of this DENSO First Time Fit® Cabin Air Filter, you must read these instructions completely.

Definition of Terms

⚠WARNING: Describes precautions that should be observed in order to prevent injury or death to the user during installation.

⚠CAUTION: Describes precautions that should be observed in order to prevent damage to the vehicle or its components, which may occur during installation if sufficient care is not taken.

NOTE: Provides additional information that facilitates installation work.

General Service Information and Requirements

⚠WARNING: To prevent the Supplemental Restraint System (SRS, Air Bag System) from operating, remove the ground (negative) cable from the battery, then wait at least 90 seconds before starting this procedure. This allows the backup power system to discharge.

NOTE: For more detailed instructions please refer to the vehicle manufacturer's service manual.

REQUIRED TOOLS:

- Safety Goggles
- Assorted Hand Tools

SAFETY PRECAUTIONS:

- Always wear safety goggles

Cabin Air Filter Removal

The information below explains necessary procedures and tools to remove and install the Cabin Air Filter (CAF).

1. Open the glove compartment and remove the passenger side upper trim panel.

NOTE: Use your nylon removal tool to prevent damaging the panel.



Fig. 1

2. Remove the hardware securing the passenger side lower trim panel beneath the glove compartment and remove it.




Fig. 2

3. Remove the hardware securing the glove compartment and remove it.




Fig. 3

4. Unlatch the CAF access cover and remove it.



Fig. 4

5. Remove the lower CAF element by pulling it towards the passenger side.




Fig. 5

6. Pull the upper CAF element in a downward motion and remove it by pulling it towards the passenger side. The original elements can be discarded.




Fig. 6

Cabin Air Filter Installation

7. Insert the upper CAF element into the HVAC housing by sliding it toward the driver side and then use an upward motion.




Fig. 7

8. Insert the lower CAF element into the HVAC housing by sliding it toward the driver side.
9. Reinstall the CAF access door and secure it. Reinstall the glove box compartment and lower trim panel and secure them with the original hardware. Reinstall the passenger side upper trim panel.




Fig. 8

Noise Test

10. Reconnect the battery ground cable.
11. Engine ON, A/C ON, blower speed on high.
12. Listen for any abnormal air noises from the air filter area.