

DIODE DYNAMICS

PERFORMANCE LIGHTING TECHNOLOGY


Always On™ Module for Scion FR-S

Thank you for your purchase of this unique lighting module for your special edition Scion FR-S! With this module, you'll be able to keep your headlight DRL LEDs on with your headlamps.

Your order for the Always-On Module™ will include TWO modules, one for each side of the vehicle. Installation will only take a few minutes.



3 YEAR
WARRANTY



1. Open your hood.
2. Unplug the headlight connector on one side of the vehicle.
3. Plug the new module inline, between the headlight and vehicle harness connectors.
4. Repeat the process for the other side of the vehicle.
5. Turn on your vehicle's headlamps to confirm function. If the DRL LEDs are not illuminated with the headlamps, please ensure the plugs are securely connected, and fully plugged in.

Please note: When the headlamps are on, the DRL LEDs will illuminate at half brightness. During the day, while driving with the headlights off, your DRL LEDs will illuminate at full brightness.

Troubleshooting: Remember, this module does not affect the factory DRL function. If you believe your DRLs are no longer working during the day with the module installed, remove the module, and ensure the DRLs turn on. **The factory DRL only turns on when the car is started, the shifter is in "Drive", AND the e-brake is fully released.**