


Cable Attachment Method



WARNING: Keep at least 3 turns of cable on winch drum at all times.