



How to Use Your DELUXE ROLLER BAG

Your E-Z UP® Shelter is ready to be placed in the Deluxe Roller Bag after the Shelter has been completely taken down.

A.
Open Deluxe Roller Bag by unzipping the heavy duty zipper near the base.


B.
Place open end of bag over the top of the E-Z UP® Shelter and slide bag down until completely covered.

C.
Carefully rotate the E-Z UP® Shelter by placing it on its top. **Note: Make sure to bend knees slightly so back strain does not occur.** Pull over the bag base plate over the feet of the Instant Shelter and zip bag closed.

D.
Rotate once more so the wheels are on the ground. Grasp the top and side handle and lift bag upright. **Note: Make sure to bend knees slightly so back strain does not occur.** Feel free to conveniently store the Shelter owner's manual in the Deluxe Roller Bag side pouch.

E.
Deluxe Roller Bag is designed to be pulled by the handles or pushed by grasping upper portion of frame.

ENJOY your E-Z UP Deluxe Roller Bag.



The #1 Instant Shelter® Brand in the World

Check out the collection of tents & accessories we offer.