




INSTALLATION SHEET

ON/OFF AND PATTERN SELECT SWITCH PANEL

THIS SWITCH PANEL WILL PROVIDE ON/OFF CONTROL OF A DEVICE AND FLASH PATTERN SELECTION ON THOSE PRODUCTS WHICH HAVE A SINGLE WIRE FLASH PATTERN SELECTION SYSTEM.

CONNECTION DIAGRAM:



THE PATTERN SELECTION SWITCH IS A MOMENTARY PUSH-BUTTON WHICH SUPPLIES +12V TO BLUE WIRE WHEN PRESSED.

SEE THE INSTRUCTION MANUAL OF THE DEVICE BEING CONNECTED TO THIS SWITCH PANEL FOR DETAILS OF HOW THE FLASH PATTERN IS CHANGED.

22-18
22-18
22-18
22-18

SPLICES INCLUDED

SWITCH WIRING REFERENCE:

