

EGR

INSTALLATION INSTRUCTIONS



- Do not use power tools to install this product.
- No battery operated screw guns.
- The use of power tools during installation may void the product warranty.
- Do not overtighten.

INSTALLATION INSTRUCTIONS

- 1 • Trial fit **HOOD PRODUCT** centrally on hood.
 - Note holes in hood corresponding to 5 slots in **HOOD PRODUCT**.
 - Remove **HOOD PRODUCT**.
- 2 • Install plastic screw plugs into holes previously noted.
- 3 • Secure **HOOD PRODUCT** to hood using screws and washers provided.

Note: On vehicles with limited hood to grill clearance it may be necessary to adjust hood bump stops. (Refer owners manual).

To Remove: Loosen and remove screws. Lift **HOOD PRODUCT** away from hood.
To Clean: Use mild detergent and water solution. (Do **NOT** use solvents). Avoid the use of automatic "Brush Style" car washes.
When closing the hood, do **NOT** pull on **HOOD PRODUCT**.

