

# INSTRUCTION SHEET FOR SET#'s 4.3119, 4.3121, 4.3124, 4.3133




Except for set 4.3133, you must reuse your metal shell that is pressed into your I-beam, do not damage this shell.


For set 4.3124, the round thrust washer #3168 will fit around the oval bushing.

Remember to thoroughly coat the polyurethane bushing, the shell I.D., and the sleeve with grease. (All surfaces that contact with metal)

## 4.3119



## 4.3121



## 4.3124



## 4.3133

