febi*tip*





Need to check the oil level in a Mercedes-Benz 5-gear auto gearboxes (722.6)? No problem!

The oil level in an auto gearbox should be checked after an oil change or if there is a suspected leak. No dipstick is provided for the gearbox at the factory.

febi bilstein has the solution!

The filler tube is located in the engine compartment (Fig. 1). The locking cap of the filler tube has a safety device to secure it against accidental opening. The disk of the locking pin has to be broken off using an appropriate tool before measuring the oil level (Fig. 2); remove the locking pin and remove the locking cap (Fig. 3).











Attention!

When checking the oil level, insert the dipstick into the filler tube as far as it will go. The filler tube differs in length as the gearbox referred to above is used in various models. Part of the dipstick may protrude from the tube once the dipstick has reached the bottom of the gearbox (Fig. 4).

Be sure to remove the dipstick after measuring the oil level! The locking cap can be secured again with a new locking pin (febi 44204).



