




HOLLEY PREMIUM AIR FILTER CLEANING INSTRUCTIONS

1. Pre-clean by lightly tapping the filter to loosen any embedded dirt particles. If any dirt remains, then lightly brush with a soft bristle brush. (If this step has sufficiently cleaned the filter element, then simply re-oil and re-install.)



2. SPRAY an ample amount of Mr. Gasket Air Filter Cleaner (P/N 78060G comes with cleaner and oil) on the entire filter element and let it soak in for approximately 10 minutes. Only use recommended premium air filter cleaners, because harsh detergents, cleaning solutions, or solvents can damage the filter element and impair its ability to work effectively.




3. RINSE the element with LOW-PRESSURE water from the clean side through the filter to the dirty side. This removes the dirt without washing it deeper into the cotton mesh of the filter element.

4. Allow the filter to dry naturally without the aid of compressed air or heat dryers. Compressed air can blow a hole in the cotton mesh and excessive heat can cause it to shrink; both of which can impair the element's ability to work effectively.

5. Apply a light, even coat of Mr. Gasket Air Filter Oil to your filter. Allow the oil to soak into the filter before installation.

IMPORTANT! You must never use a *Holley Premium Air Filter* without filter oil. The oil prevents dirt from passing through the filter element.

6. RE-INSTALL your *Holley Premium Filter*, making sure that the element seats properly in the filter case. Replace the cover, add any bolts, clips, etc. and tighten to factory specifications.



Your *Holley Premium Air Filter* will need to be cleaned and re-oiled in 50,000 to 100,000 miles!