


## Hooker 1964-72 GM A-Body 4L60-4L70 Transmission Spacer 12657HKR Installation Instructions



Thank you for choosing to use this Hooker<sup>™</sup> component as part of your performance project. This bracket is compatible for use with the Hooker **71222007HKR or 71222008HKR** A-body transmission crossmembers only. Please read these instructions in their entirety before attempting installation.

## **PRE-INSTALLATION CONSIDERATIONS:**

This spacer is designed to provide the user of a Hooker **71222007HKR or71222008HKR** transmission crossmember with the means to install a GM 4L60-4L70 automatic transmission behind an LS engine in any 1964-72 A-body vehicle. Attachment bolts to connect the transmission mount to the crossmember are not included and are to be user sourced.

## <u>CAUTION!</u> WORK ONLY ON A LEVEL SURFACE. USE JACKS /JACK STANDS OF SUFFICIENT CAPACITY TO LIFT AND SUPPORT YOUR VEHICLE. NEVER WORK UNDER A VEHICLE SUPPORTED BY A FLOOR OR BUMPER JACK.

## **INSTALLATION:**

- **NOTE:** These instructions have been written with the assumption that your transmission and Hooker transmission crossmember has been installed into the vehicle.
- 1. Check that the hardware package includes the following:
  - (1) Machined aluminum spacer
- 2. Raise the rear of your transmission and install this spacer block between the lower cantilevered shelf of the crossmember and transmission isolator mount.
- 3. Attach the transmission mount, spacer, and crossmember together with user-supplied hardware of your choice (Grade 8 recommended).