



This adapter has the capability to change the electric brake and battery pin locations adapting to different codes.

## WIRE IDENTIFICATION

GD = Ground, white wire TM = Tail, brown wire LT = Left Turn, yellow wire RT = Right Turn, green wire AX = Battery, black wire EB = Electric Brakes, blue wire

To change wiring functions, remove screws and switch the black and blue wires.

NOTE: Locate wires and pin location by function only. Color coding is not standard among all manufacturers.