




# #47715



The location of the vehicle connector for 1994-98 F-Series Pickups can be found at the arrow marked "B". All other applications listed can be located at the arrow marked "A".

1. Plug the Hopkins® connector into the vehicle connector located under dash.
2. Plug mating end of the Hopkins® [connector](#) into the brake control.
3. Test all functions.