



HURST SHIFTER CABLE SUPPLEMENT

Hurst has made an improved design change in the gear selector cable for this shifter. The new cable supplied is adjustable at the threaded end. Disregard cable installation at transmission oil pan bracket and transmission arm in Hurst instruction sheet.

SHIFTER CABLE INSTALLATION

1. Insert shifter cable into mounting bracket and secure using clip. Push clip onto cable inside of bracket with tab facing rearward and tap in until fully seated.
2. Install cable pivot onto threaded end of shifter cable. Adjust pivot on end of cable until it slides freely into hole in transmission arm. Lock adjustment by tightening hex nut against pivot. After inserting pivot, secure using cotter pin.

Note: It may be necessary to make a fine adjustment of cable pivot before shifter will engage completely.