


Honda Accord 2004-2006 Non-Navigation Radios Satellite Radio Operation

****READ THIS FIRST****

Changing Sources (Factory SAT and Bluetooth)

- Press the XM or AUX button.
- XM1 remains Factory SAT (if equipped).
- XM2 becomes the Bluetooth source.

(Actual radio appearance may differ from representation.)



Example:

Adjusting the output gain

- 1) Press Preset 4 to access the output gain adjustment.

Radio text will clear and the channel number will be the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest and 9 being the highest.



- 2) Within 7 seconds press preset 5 to lower the gain and preset 6 to raise the gain.


Channel number on the radios display will change accordingly.



- 3) 7 seconds after the last button press the level will be stored and the track text will reappear on the radios display.

Honda

Accord 2008-2011 Non-Navigation Radios CD Changer Operation



Example:

Adjusting the output gain

- 1) Press the Repeat button to access the output gain adjustment.

The track number will change to the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest level and 9 being the highest.

- 2) Within 7 seconds press Disc - to lower the gain and Disc + to raise the gain.

The track number on the radios display will change accordingly.

- 3) 7 seconds after the last button press the level will be stored and the track number will change to the number of the current track.

Honda Accord 2008-2011 Non-Navigation Radios Satellite Radio Operation


****READ THIS FIRST****

Changing Sources (Factory SAT and Bluetooth)

- Press the XM or AUX button.
- XM1 remains Factory SAT (if equipped).
- XM2 becomes the Bluetooth source.

(Actual radio appearance may differ from representation.)

- Press to connect with the next paired device.
- Press 5 times to clear all devices.
- Press to initiate the Play/Pause command while streaming audio.
- Press tune down to end a call.
Press tune down to reject an incoming call.
Press tune down to return to the previous track while streaming audio.



- Press 5 times to initiate pairing mode.
- Press to initiate Voice Recognition.
- Press to access the output gain adjustment.
- Press tune up to answer a call.
Press tune up to advance to the next track while streaming audio.
Press tune up to enter privacy mode while in a phone call.

Example:

Adjusting the output gain

- 1) Press Preset 4 to access the output gain adjustment.

Radio text will clear and the channel number will be the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest and 9 being the highest.



- 2) Within 7 seconds press preset 5 to lower the gain and preset 6 to raise the gain.

The channel number on the radios display will change accordingly.



- 3) 7 seconds after the last button press the level will be stored and the track text will reappear on the radios display.


Honda/Acura Non-Navigation Radios CD Changer Operation

(Actual radio appearance may differ from representation.)

Press the CD/AUX or AUX button to enter the Bluetooth source

Press Repeat to access the output gain adjustment.
Press Repeat 5 times to initiate pairing mode.

Press Random to connect with the next paired device.
Press Random 5 times to clear all devices.



Press tune down or turn the tune dial counter-clockwise to:

Reject an incoming call.
Return to the previous track while streaming audio.
To end a call.

Press tune up or turn the tune dial clockwise to:

Advance to the next track while streaming audio.
Answer a call.
Enter privacy mode while in a phone call.

Press Disc + to initiate the Play/Pause command while streaming audio.

Press Disc - to initiate Voice Recognition.

Example:

Adjusting the output gain

1) Press the Repeat button to access the output gain adjustment.

The track number will change to the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest level and 9 being the highest.

2) Within 7 seconds press Disc - to lower the gain and Disc + to raise the gain.

The track number on the radios display will change accordingly.

3) 7 seconds after the last button press the level will be stored and the track number will change to the number of the current track.

Honda/Acura Non-Navigation Radios Satellite Radio Operation

****READ THIS FIRST****

Changing Sources (Factory SAT and Bluetooth)

- Press the XM or AUX button.
- XM1 remains Factory SAT (if equipped).
- XM2 becomes the Bluetooth source.


(Actual radio appearance may differ from representation.)

Press to initiate the Play/Pause command while streaming audio.

Press 5 times to clear all devices.

Press to connect with the next paired device.

Press to access the output gain adjustment.



Press tune down or turn the tune dial counter-clockwise to:

Reject an incoming call.
Return to the previous track while streaming audio.
to end a call.

Press tune up or turn the tune dial clockwise to:

Advance to the next track while streaming audio.
Answer a call.
Enter privacy mode while in a phone call.

Press to initiate Voice Recognition.

Press 5 times to initiate pairing mode.

Example:

Adjusting the output gain

- 1) Press Preset 4 to access the output gain adjustment.

Radio text will clear and the channel number will be the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest and 9 being the highest.



- 2) Within 7 seconds press preset 5 to lower the gain and preset 6 to raise the gain.

The channel number on the radios display will change accordingly.



- 3) 7 seconds after the last button press the level will be stored and the track text will reappear on the radios display.


Honda Accord 2004-2006 Non-Navigation Radios Satellite Radio Operation

****READ THIS FIRST****

Changing Sources (Factory SAT and Bluetooth)

- Press the XM or AUX button.
- XM1 remains Factory SAT (if equipped).
- XM2 becomes the Bluetooth source.

(Actual radio appearance may differ from representation.)



Example:

Adjusting the output gain

- 1) Press Preset 4 to access the output gain adjustment.

Radio text will clear and the channel number will be the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest and 9 being the highest.



- 2) Within 7 seconds press preset 5 to lower the gain and preset 6 to raise the gain.

Channel number on the radios display will change accordingly.



- 3) 7 seconds after the last button press the level will be stored and the track text will reappear on the radios display.


Honda Accord 2004-2006 Non-Navigation Radios CD Changer Operation

(Actual radio appearance may differ from representation.)

Press the CD/AUX or AUX button to enter the Bluetooth source.

Press seek down to end a call.
Press seek down to reject an incoming call.
Press seek down to return to the previous track while streaming audio.

Press seek up to answer a call.
Press seek up to advance to the next track while streaming audio.
Press seek up to enter privacy mode while in a phone call.



Press Repeat to access the output gain adjustment.
Press Repeat 5 times to initiate pairing mode.

Press Random to connect with the next paired device.
Press Random 5 times to clear all devices.

Press Disc + to initiate the Play/Pause command while streaming audio.

Press Disc - to initiate Voice Recognition.

Example:

Adjusting the output gain

1) Press the Repeat button to access the output gain adjustment.

The track number will change to the current gain level. The level can be adjusted from 1 - 9 with 1 being the lowest level and 9 being the highest.

2) Within 7 seconds press Disc - to lower the gain and Disc + to raise the gain.

The track number on the radios display will change accordingly.

3) 7 seconds after the last button press the level will be stored and the track number will change to the number of the current track.