





JLT 3.0 Oil Separator (2015-18 Transit 150/250/350 3.5 Ecoboost Passenger side)
#3025P
Installation Instructions

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) JLT Oil Separator, (1) angled mounting bracket, (2) fine thread machine screws
2	Gather all of the following tools needed for the installation: Phillips screw driver, and T30 Torx driver/bit Remove factory PCV Line here, pull grey tab away from fitting and pull assembly outward.
3	 A photograph of the engine compartment of a vehicle. Two white arrows point to the PCV line assembly located near the center of the engine. The engine cover is partially visible, and various hoses and components are present.
4	Remove T30 Torx screw from upper power steering reservoir bracket. Install JLT bracket and reinstall factory Torx screw.
5	Use supplied screws to mount the bracket onto the Oil Separator as shown:  A close-up photograph showing the JLT oil separator being mounted. A metal bracket is being attached to the side of the oil separator. Two white arrows point to the screws that are used to secure the bracket to the separator. The oil separator has a black cap with yellow markings.

Run hoses to factory PCV connections and you're done!



6

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business.