

**JLT 3.0 Oil Separator, Passenger Side
(2011-14 Mustang GT with Roush / VMP, Whipple or FRPP Supercharger;
2015-19 Mustang GT with Roush / VMP Supercharger)
#3020P
Installation Instructions**

Please review complete instructions prior to installing.

Remove the stock line from the valve cover, supercharger and hose fitting behind the reducer.



Remove at last squeeze

1

Insert JLT assembly into the hose and reinstall the clamp.



2

Connect fittings to the valve cover and supercharger and you're done.



3

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business.