





JLT 3.0 Oil Separator (2017-18 Ford Fusion Sport EcoBoost 2.7L V6 Passenger Side) #3034P  
Installation Instructions

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) JLT Oil Separator, (1) mounting bracket, (2) fine thread machine screws, (1) Mounting Bolt
2	Gather all of the following tools needed for the installation: 8mm wrench, 10mm socket, extension and ratchet, & Phillips screw driver
3	Remove engine cover by removing 10mm Bolt and 10mm nut. Pull up on engine cover to release.
4	Remove factory PCV line by pulling tabs and pulling it off of the engine. 
5	Locate 8mm bolt that holds a bracket on the passenger side of the engine and remove bolt. Install JLT Bracket in the same location and reinstall bolt. You can either reuse factory bolt, or supplied bolt with kit. 

Install JLT can onto JLT Bracket using the two supplied screws. Route short hose to PCV valve on valve cover(90 degree fitting), sweep longer hose and hook to intake manifold(45 degree fitting)



Reinstall engine cover and you're done!

To service can- you will need to remove the can from the vehicle as this engine bay is very tight on space.

To remove fittings, press large grey button inward to release and pull upward on fitting. You do not need to remove the grey clips from the fittings!

6

To properly clean the filter in the Oil Separator spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles. Thanks for the business.