




JLT 3.0 Oil Separator (2019 Chevy Silverado 1500/GM Sierra 1500 5.3L V8, Driver Side)
#3086D

Please review complete instructions prior to installing.

Step#	
1	Verify you have all of the following parts included in the kit: (1) JLT Oil Separator with hoses, (1) mounting bracket, (2) M4 screws, (1) M6 Nut
2	Gather all of the following tools needed for the installation: 10mm socket, ratchet and extension, Phillips screw driver, 5/16" Nut driver or Flat head screwdriver.
3	Remove stock intake box by loosening clamp at Throttle body and MAF housing. Remove breather hose on passenger side of intake box by depressing grey button and pulling away from box. Once these are disconnected you can rotate the box towards the passenger side up and out of the way.
4	<p>Located and remove stock PCV hose from PCV valve(driver side valve cover) and intake manifold. Depress grey tabs to release hose.</p> 
5	Assemble JLT Oil separator onto mounting bracket, line up logos for proper orientation. Use supplied screws to secure bracket.

Remove 10mm bolt holding coolant overflow tank



With this bolt removed, you can pivot the tank off the front stud on the fire wall. You will install the JLT assembly onto this stud with the supplied nut. Tight nut down and reinstall coolant tank and bolt.

6

Run the short hose to the PCV valve(valve cover)the connections will "click" once fully seated. Run the longer hose to the intake manifold valve, route hose around oil fill as shown below.



7

Reinstall intake system and you're done!

To properly clean the filter in the Oil Separator, spray any degreaser or solvent through it and let it air dry. Clean it every 10,000 miles.

Thanks for the business.