



Loosen locknuts on back of Mounting Station.



Move all adjustments on Mounting Station to make a snug fit onto tablet.



UNIVERSAL TABLET

Mounting Station

Model No. 450-4119



Place your tablet into Mounting Station



Lock your mounting station.



Flip mounting station over onto face.



Tighten all locknuts.

DESIGNED TO FIT MULTIPLE TABLETS WHEN USED WITH AN OTTER BOX® or SIMILAR CASE.

Adjustable to fit tablets from 7.18 - 8.3" height x 9.84 - 12.5" width and 0.84" deep

* We recommend use of a protective case to further secure tablet and prevent vibration against metal parts.