



Loosen locknuts on back of Mounting Station.



Move all adjustments on Mounting Station to make a snug fit onto tablet.



UNIVERSAL TABLET

Mounting Station

Model No. 450-4119



Lock your mounting station.



Flip mounting station over onto face.



Place your tablet

Mounting Station

Tighten all locknuts.

DESIGNED TO FIT MULTIPLE TABLETS WHEN USED WITH AN OTTER BOX® or SIMILAR CASE.

Adjustable to fit tablets from 7.18 - 8.3" height x 9.84 - 12.5" width and 0.84" deep

* We recommend use of a protective case to further secure tablet and prevent vibration against metal parts.