

USER GUIDE AND INSTALLATION MANUAL BRAKE LIGHT TURN SIGNAL MODULE



AUTEC7

Programmable Control Module

The **AUTEC7** is perfect for cars with only a brake light circuit- it allows you to keep your simple brake light setup, but adds independently flashing right and left brake lights for full indicator legality on the road.



IMPORTANT INFORMATION!

- 1** You must use relays on ALL outputs except for Status LED output.
- 2** All outputs are negative trigger.

Unit Operation

NOTE:

Module must be installed after turn signal switch & flasher.

Additional Parts:

AUTRA1000 Relay (2)

AUTRAS12 Relay Harness (2)

