



## INSTALLATION INSTRUCTIONS

**PART No.** 30480

**MODEL No.**

Gas Filler Neck



Remove the gas cap and the plastic holding strap.  
Remove the eight screws holding the existing filler neck.  
Install the new Stainless Steel gas filler neck using the stainless screws provided. The four 3/4" Lg. Screws go on the outside and the long screws go on the inside.




## INSTALLATION INSTRUCTIONS

**PART No.** 30480

**MODEL No.**

Gas Filler Neck



Remove the gas cap and the plastic holding strap.  
Remove the eight screws holding the existing filler neck.  
Install the new Stainless Steel gas filler neck using the stainless screws provided. The four 3/4" Lg. Screws go on the outside and the long screws go on the inside.