



INSTALLATION INSTRUCTIONS

Part Number: E-2443

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures **MUST** be followed to ensure the proper fit and seal of the K&N® air filter.

INSTALLATION:

1. Remove the OE filter according to owner's manual.
2. Wipe away any dirt and dust from the inside of the air filter housing. (Fig. 1)

NOTE: A damp cloth can be used to clean the inside of the air filter housing.

3. Install the K&N® air filter into the airbox base. Make sure the inside diameter of the K&N® air filter slides completely over the protruding register of the airbox base. The base of the K&N® air filter must sit flat against the rubber seal in the base of the airbox to ensure a proper seal. (Fig. 2 & Fig. 3)
4. Reinstall the airbox lid, refasten the airbox clamps and tighten the wing nut.

THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.



Fig. 1



Fig. 2



Fig. 3