



# INSTALLATION INSTRUCTIONS

## Part Number: 33-5026

This filter fits: See catalog for current applications

Congratulations, you have purchased the finest air filter that money can buy. With proper care, this filter will last 1 million miles or more. This filter is a direct replacement for the stock air filter, and no modification will be required. However the following procedures MUST be followed to ensure the proper fit and seal of the K&N® air filter.

### INSTALLATION:

1. Remove the stock filter.
  2. Place the K&N® filter in the K&N® frame with the filters logo facing the frames cut outs. (See fig. 1)
  3. Apply the supplied K&N® grease to the seal to ease installation. (See fig. 2)
  4. Install the K&N® filter by pushing the frame with the filter into the air box. (See fig. 3, 4)
- NOTE: Ensure that the seal is resting inside the air box by pushing the frame in completely.** (See fig. 5)
5. Install the lid on the air box.

### CLEANING:

K&N Engineering, Inc., suggests checking the air filter element periodically for excessive dirt build-up. Depending on your driving conditions, we recommend cleaning your air filter every 50,000 miles. To clean and re-oil, purchase our filter Recharger® service kit, part number 99-5050 or 99-5000 and follow the easy instructions.

**THESE INSTRUCTIONS MUST BE FOLLOWED EVERY TIME THE FILTER IS SERVICED, OTHERWISE THE FILTER MAY NOT SEAL, AND DAMAGE TO THE ENGINE COULD RESULT.**



fig. 1



fig. 2



fig. 3



fig. 4



fig. 5