



Digital Tire Gauges

#50345/53006 0-60 psi

#50347/53036 0-100 psi

Push **ON** to turn gauge on. Gauge shuts off automatically after 3 minutes. Turn back on if needed. Gauge auto-zeros at turn on. If zeroing is ever needed push ON and hold for 3 seconds.

• DO NOT DROP THE UNIT. KEEP IT CLEAN AND DRY. DO NOT EXPOSE TO STRONG ELECTROMAGNETIC FIELDS (caster/camber gauge magnets?). **DO NOT EXCEED RATED PRESSURE.** This unit runs approx. 1000 hours on the internal battery. When the Low Batt indicator appears in the upper right of the display (see below) replace w. a quality SR2032 'coin' style battery. Access is on the back of the gauge.

To convert to metric - Bar or other - following the instructions below:

- Turn gauge on. When 0.0 appears push AND HOLD the **UNITS** button on the right side.
- After 3 seconds the unit indication will start to flash. This is along the top of the display. PSI on the upper left.
- Release the UNITS button, then push again to change. Options are PSI, BAR, Kgm/cm², and kPa.
- Once you have reached your selection stop pushing the button. The gauge will return to normal function in 5 seconds.

