

Longacre



Ultimate Digital Tire Pressure Gauge

TO TAKE PRESSURES: Turn unit on (auto-Zeros at turn on - DO NOT TURN ON w. pressure on gauge). If Zero is needed quickly tap **ON/OFF** button. To turn off hold **ON/OFF** button 1 sec. True factory calibrated pressure will be shown. **Be sure** TRUE FACTORY Calibration **is on the display in the lower right**. If not push **LOCK TEMP** button.

TO SAVE THIS PRESSURE TO THE DISPLAY: Push the **STORE MEMORY** button. That pressure will be stored on the display. Start at the Right Front, then the Right Rear, Left Rear, then Left Front. Once you have all 4 pressures no more can be stored without clearing. If you have stored the wrong pressure push and hold **STORE MEMORY** 2 seconds. The last reading will be cleared. Release button and retake pressure. To clear all 4 continue to hold **STORE MEMORY** for 3 seconds.



All 4 tire pressures displayed

Nite light

Indicates actual true pressures (NOT compensated)

