



INSTALLATION INSTRUCTIONS FOR COIL SPRING INSULATORS

Note position of original insulators during removal. Be sure to install replacement insulators in the same location as those removed.

WARNING

Do not install more than one insulators on each end of the spring. The use of more than one insulators per end may cause the spring to unseat during installation or use and serious injury could result.

NOTE: The parts in this kit are designed to replace the worn or non-functioning original equipment parts in the vehicle as produced by the car factory. These parts are not designed for installation on vehicles where the suspension and/or steering systems have been modified for racing, competition, or any other purpose.