



THE AUTOMOTIVE LIGHTING BENCHMARK

INSTALLATION INSTRUCTIONS

16+ CAMARO SEQUENTIAL TAIL LIGHTS

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its distributors make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below, professional installation is recommended.

PACKAGE CONTENTS



2X TAIL LIGHT ASSEMBLIES

INSTALLATION PROCESS

1. Open trunk lid.



2. Remove the four (4) nuts holding the trunk trim on around the latch and remove the trim panel. Set aside.



3. Remove the interior panel trim clips with a Y-shaped trim removal tool or carefully with a flathead screwdriver.



4. Remove the clips securing the trim panel on top of the tail lights. Remove the board and set aside.



5. Remove the three (3) 8mm nuts holding the tail light to the vehicle.



6. Remove the original tail light.



7. To release the stock wiring connector, pull the red lock out then press the center tabs beneath it to release the connector's latch.



8. Fit the new sequential tail lights. Secure by re-installing the original three (3) 8mm nuts from the inside of the trunk.




9. The two circled connectors are for controlling the sequential function.

10. Test the new housings' functions. Once satisfied, re-assemble trim panels in reverse order and enjoy!



SEQUENTIAL TURN SIGNAL OPERATION



STANDARD (BLINKING) TURN SIGNAL OPERATION

