



THE AUTOMOTIVE LIGHTING BENCHMARK

2005-2013 CORVETTE XB LED HEADLIGHTS INSTALL GUIDE

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its dealers make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. If you are unable to clearly understand and adapt the information below, professional installation is recommended.






IMPORTANT: If your vehicle is equipped with anything but OEM turn signals (full assemblies, LED bulbs, or otherwise) in the tail lights or elsewhere: You may experience a hyper flash and/or problem with the sequential signal setting on these headlights. This is not a defect in the headlight, and caused by un-matched impedance with your original vehicle settings.


PARTS IDENTIFICATION

STANDARD PARTS

2x HEADLIGHT HOUSINGS




1x DRL HARNESS




WIRING CONFIGURATION AND INSTALLATION

WIRING DIAGRAM



DRL WIRING




SEQUENTIAL TURN SIGNAL



MAIN CONNECTION

DRL HARNESS WIRING

DRL WIRE FROM
LEFT HEADLIGHT




DRL WIRE FROM
RIGHT HEADLIGHT


INSERT FUSE TAP
TO ACC IN FUSEBOX
(FUSE #6 HAS HAD
GOOD FEEDBACK)

DRL SPLITTER /
FUSE TAP

SEQUENTIAL TURN SIGNAL CONTROL



DISCONNECTED:
SEQUENTIAL TURN SIGNAL FUNCTION



CONNECTED:
STANDARD TURN SIGNAL FUNCTION