



Oil Restrictor Kit
PART #20000

WARNING: Do NOT use with hydraulic lifters

INSTALLATION INSTRUCTIONS

Installs into cam journal.

Parts List

2- 5/16"-18 restrictors with .060" orifice dia.

1. Remove freeze plug and camshaft bearing.
2. Tap the two oil gallery holes to accept the 5/16"-18 plugs and remove all metal chips.
3. Apply red Loctite® to restrictor threads and install.
4. Replace bearing and freeze plug.

Note: The .060" pre-drilled orifice is suitable for most wet/dry oiling systems. If your engine setup requires greater oil flow, simply enlarge (drill) the orifice in each plug.