



11mm Spark Plug Wire Separator Kit

Use the appropriate 2 -, 3 -, or 4 - hole separator at any location on the ignition wires between the distributor and spark plugs to keep wires away from hot engine parts and other potential trouble spots. (NOTE: to achieve a more secure routing formation use Moroso Loom Kits, which include chrome mounting brackets, looms and separators).

Wires simply "snap" into place. Silicone spray lubricant helps ease the wires into the openings. When routing the ignition wires, be sure they clear exhaust headers. Always remove and install ignition wires from the boots, do not pull on the wire.