



Step 1: Remove fuse box cover hold down screw



Step 2: Remove fuse box cover







Step 3: Thread wire tie thru as shown in above





Step 4: Repeat on other side



Step 5: Pull evenly on wire ties until mounting stud is released







Step 6: Cut and remove wire ties from fuse box cover



Step 7: Reinstall stock fuse box cover



Step 8: Place new fuse box cover over "stock" fuse box cover



Step 9: Reinstall hold down screw

