

Change-Over Relay

#40100G – 2” x 3.5”

Switches current from one user to another (opening to closing power window). Use wire gauge & fuse listed by component's mfg. Connector has 12 & 18 gauge leads.

WIRING DIAGRAM:

#85 GROUND

#86 SWITCH

#30 BATTERY (+)

#87 NORMALLY OPEN CIRCUIT (OFF) – closes circuit allowing current to pass through such as vehicle lighting, horns, or fan motors

#87a NORMALLY CLOSED CIRCUIT (ON) – interrupts current for short time such as radio when engine starts.

