

MSD[®] **IGNITION** **INSTALLATION INSTRUCTIONS**

Coil Wire Retainer **PN 8217**

Parts Supplied

1 – Coil Wire Retainer 1 – Spacer
1 – Wire Tie

WARNING: High voltage may be present on the coil terminals. Do not touch the coil terminals while the engine is cranking or running!

The Coil Wire Retainer is designed to work with MSD Blaster Coils that have a canister style housing and other canister type coils.

Coils with a short coil tower will require the use of the supplied spacer ring. Slide the spacer ring up from the bottom of the coil to the upper lip, then clamp the coil retainer over the coil. Coils with tall towers do not require the use of the coil spacer ring.

After clamping the retainer over the coil and coil wire, use the supplied wire tie to secure it in place.



Figure 1

Limited Warranty

MSD IGNITION warrants this product to be free from defects in material and workmanship under its intended normal use*, when properly installed and purchased from an authorized MSD dealer, for a period of one year from the date of the original purchase. This warranty is void for any products purchased through auction websites. If found to be defective as mentioned above, it will be repaired or replaced at the option of MSD Ignition. Any item that is covered under this warranty will be returned free of charge using Ground shipping methods.

This shall constitute the sole remedy of the purchaser and the sole liability of MSD Ignition. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representation whether expressed or implied, including any implied warranty of merchantability or fitness. In no event shall MSD Ignition or its suppliers be liable for special or consequential damages.

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD Ignition. Any modifications to this item or if it is used on an application other than what MSD Ignition markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD Ignition will accept no liability for custom applications.