

Installation Guide


REAR CONTROL ARM OUTER BEARING

Z 5236

Suits: Ford Falcon AU Series

(Always refer to the current catalogue for complete application listings)

N.B: This installation guide should be used in conjunction with the workshop manual.
All fastener torque settings should be adhered to.



Note: Instructions are for AU series only.

N.B: It is recommended that a licensed workshop or trades person carry out the above procedure and that workshop manual and relevant safety procedures are followed in addition to the above.